

O W N E R S M A N U A L
CD Players



page	
1	1.0 Equipment Installation
	1.1 cables and connections
2	2.0 Getting Started
	2.1 switching on and off
	2.2 running in
	2.3 mains supply
	2.4 siting the equipment
	2.5 if you have a problem
3	3.0 Warnings
4	4.0 Connection
	4.1 mains lead
	4.2 non-rewireable mains plugs
	4.3 fuse carrier
	4.4 plug fuses
5	CDS Player
10	CDX Player
14	CD5 Player
18	Narcom 2 Remote Control
20	CD Player Maintenance, Specifications
21	EC Declaration of Conformity to Appropriate Standards

1.0 Equipment installation

Normally your Naim equipment will have been installed by the dealer who sold it to you even if you live outside their immediate vicinity. Your dealer is responsible for making sure that the system sounds exactly as it should and information given here is not intended to reduce this responsibility in any way.

1.1 cables and connections

Please do not modify the standard interconnect cables supplied with your Naim equipment. This is important for safety as well as performance. One end of each cable is marked with a band to establish its correct orientation. The band always marks the end that connects to the signal source.

Loudspeaker leads are also very important. Naim loudspeaker cable is correct for your system and your dealer will make up leads to suit your equipment installation. The leads should each be at least 3.5 metres long and of equal length. The recommended maximum is 20 metres. Loudspeaker leads are, like interconnect leads, directional, and should be connected so that the printed arrow points towards the speakers. Using alternative loudspeaker cable will degrade performance, and may even damage your amplifier. An exception to these loudspeaker cable constraints is the **nap 6-50** multi-room power amplifier. The **nap 6-50** is designed to be tolerant of both a wide variety of cable types, and cable runs well in excess of 20m. The loudspeaker connectors supplied with all Naim amplifiers and loudspeakers have been specifically designed to make a robust mechanical connection. It is essential that these are used in order to comply with current European safety regulations.

All the plugs and sockets supplied with your Naim equipment have been chosen because they make the best possible connection for their purpose. A poor contact will degrade the signal substantially and plugs and sockets should look clean and free from corrosion. The easiest way to clean them is to switch off the equipment, pull the plugs out of their sockets, and push them back in again. Special contact cleaners and contact enhancers should not be used as they tend to deposit a film which is very difficult to remove and may degrade the sound.

2

2.0 Getting Started

2.1 switching on and off

Source components and power supplies for cd players, tuners, preamplifiers and crossovers should be switched on before switching on the amplifier(s). Always switch the amplifier(s) off and wait about a minute for its power supply capacitors to discharge before connecting or disconnecting any leads. Always use the power switch on the product rather than a mains outlet switch.

2.2 running in

Your Naim equipment will take a considerable time to run-in before it performs at its best. The duration varies, but under some conditions you will find that the sound continues to improve for as much as five weeks. Better and more consistent performance will be achieved if the system is left switched on for long periods. It is worth remembering however that all electronic equipment can be damaged by lightning. Please read the warnings section.

2.3 mains supply

Where fused plugs are used 13 amp fuses should be fitted. Fuses of a lower rating will fail after a period of use.

A hi-fi system usually shares a mains circuit with other household equipment some of which can cause distortion of the mains waveform. In some Naim equipment such distortion can lead to a mechanical hum from the transformers. The hum is not transmitted through the speakers and has no effect on the performance of the system but is purely local to the transformer itself. A separate fused mains circuit (like that reserved for electric cookers) may reduce transformer hum. Such a circuit (ideally with a 30 or 45 Amp rating) will also have a lower impedance, supply cleaner power, and consequently improve system performance.

Do not wire voltage dependent resistors or noise suppressors into mains plugs. They degrade the mains supply and the sound.

2.4 siting the equipment

Power supplies and amplifiers should be located a reasonable distance away from other equipment. This separation will stop transformer radiation causing hum audible from the loudspeakers. The minimum recommended distance is 300mm (12 inches), and that allowed by the standard interconnect lead is the maximum.

Some Naim equipment is extremely heavy. Ensure that your equipment rack or table can easily support the weight and is stable.

2.5 if you have a problem

Legal consumer protection varies from country to country. In most territories a dealer must be prepared to take back any Naim equipment he has sold you if he cannot make it work to your satisfaction in your own home. A problem may be due to a fault in any part of the system or its installation so it is essential to make full use of your local dealer's diagnostic skills on site. Please contact your local distributor, or Naim at the address in the back of this manual, if any difficulties cannot be resolved. Some Naim equipment is made in special versions for different territories and this makes it impracticable to arrange international guarantees. Please establish the guarantee arrangements with your own dealer at the time of sale. We are always available to offer help and advice.

It is essential that repairs and updates are only carried out by an authorised Naim dealer, or at the factory by Naim itself. Many components are made, tested or matched specially for Naim and appropriate replacements are often unobtainable from non-specialist sources.

3.0 Warnings


Naim equipment is designed to offer the finest sound quality that can be achieved, avoiding compromise wherever possible. This can lead to circumstances that may be unfamiliar. The material that follows contains advice specifically related to Naim equipment as well as more general warnings about the use of domestic audio products. Please read it carefully.

The transformers in Naim power amplifiers and power supplies may sometimes make a mechanical noise caused by distortion of the mains waveform. Naim transformers are large in size and have heavy gauge secondary windings making them relatively sensitive to such distortion. A separate mains circuit for your hi-fi system may reduce the effect while also giving an overall improvement in sound quality. It may be necessary however to take account of mechanical transformer noise when siting your equipment.

In some circumstances, depending on where you live and the earthing arrangements in your home, you may experience radio frequency interference. Controls on broadcasting in some territories allow very high levels of radio frequency radiation and both the choice and exact siting of equipment may be critical. If there is a known problem in your locality it is advisable to arrange for a home demonstration before purchase to find out if Naim equipment is likely to be affected. Susceptibility to radio frequency interference is related to the wide internal bandwidth necessary for high sound quality. Systems incorporating moving coil phono preamplifiers and active crossovers are more likely to suffer. A radio frequency filter kit is available for some Naim equipment but sound quality will be progressively compromised as more elements of the kit are fitted. In situations of extreme radio interference Naim equipment may be unsuitable.

Your Naim hi-fi system can be damaged by lightning. Power amplifiers are particularly at risk and should be turned off when there is risk of lightning strike. For complete protection all mains plugs and any aerial cables should be disconnected when not in use.

Equipment must not be exposed to dripping or splashing and no objects filled with liquid, such as vases, should be placed on the equipment.



important

In order to comply with current European safety regulations it is essential that the Naim loudspeaker connectors supplied with amplifiers and loudspeakers are used.

Do not under any circumstances allow anyone to modify your Naim equipment without first checking with the factory, your dealer, or your distributor. Unauthorised modifications will invalidate your guarantee.

For your own safety do not under any circumstances open Naim equipment without first disconnecting the mains.

The following label is attached to all mains powered equipment:



4.0 Connection

4.1 mains lead

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug proceed as follows:

The wire which is coloured **GREEN-AND-YELLOW** must be connected to the terminal in the plug which is marked by the letter E or by the safety earth symbol or coloured green or green-and-yellow.

The wire which is coloured **BLUE** must be connected to the terminal in the plug which is marked with the letter N or coloured black.

The wire which is coloured **BROWN** must be connected to the terminal in the plug which is marked with the letter L or coloured red.

4.2 non-rewireable mains plugs

If a non-rewireable plug is cut from a mains lead (for whatever purpose) the plug **MUST** be disposed of in a way to render it totally unusable. Considerable shock hazard exists if the cut-off plug is inserted into a mains outlet.

4.3 fuse carrier

Should the plug fuse carrier be damaged or lost, the correct replacement must be obtained from your dealer or from Naim direct. Do not use the plug until the fuse carrier is replaced.

4.4 plug fuses

Replace only with ASTA or BS 1362 approved fuses.

note



This equipment has been tested and found to comply with the relevant EMC and Safety Standards, and, where applicable, also complies with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult your Naim dealer or an experienced radio/TV technician for help.

CDS Player Operation

cds

There are six buttons on the right hand side of the cds player front panel. Press to activate. Several of these buttons operate differently depending on whether the player is in load condition (after a disc has been loaded, but before the play button has been pressed). The player returns automatically to load condition either at the end of the disc, or at the end of the last track of a programme, or when the stop button is pressed or when the lid is opened and closed.

display

In load condition makes the player display alternate between showing:

- (a) the total number of tracks, (b) total time and (c) display off.

In play condition makes the player display alternate between showing

- (a) the number (and index number) of the track being played, (b) the time it has been played and (c) display off.

previous

In load condition searches the table of contents backwards, either one track at a time, or sequentially if you hold the button depressed. Then press PLAY to play the track chosen. In play condition mutes while searching the table of contents backwards, and then plays the track chosen without further command.

next

The next function operates in the same way as the previous function, but moving forwards through the disc instead of backwards.

pause

Mutes the sound, leaving the laser arm paused in its current position (and the disc still rotating). Pressing a second time turns the sound back on. In between, you may choose to use the previous or next functions to select a different track. To play the chosen track you will then need to undo the pause with a second press of the button.

stop

Stops the disc rotating, returns the laser to its inner position, and resets the player to load condition.

play

Causes the player to enter play condition. The loaded disc will start to play, beginning with track one, unless another track has been selected. If you press play while a track is already playing, the track will be re-started. When an HDCD encoded compact disc is loaded the CDS automatically recognises it and decodes the relevant information. The display will read HDCD for a few seconds after the play button is pressed (from load condition).

These functions are duplicated on the remote control which also provides many additional facilities. For further information please refer to the instructions on page 18.

On the far right of the display are three indicators.

track

When lit, the display shows the total number of tracks(in load mode) or track number selected (in play mode).

time

When lit, the display shows total time (in load condition) or elapsed time of track being played (in play condition). To the right of these indicators is an alphanumeric display for track and index numbers, OR time in minutes and seconds, OR various system messages (eg: play, err etc). The full stop on the right of the window comes on when the player receives a signal from the remote control.

repeat

Shows (when lit) that repeat has been selected from the remote control.



program

Shows (when lit) that a program has been stored. For further information please refer to the remote instructions on page 18.



CDS Player (from serial no. 146541)



cds player wiring





xps power supply



CDS Player (from serial no. 146541)

transit locks


- 1 Unlock the transit screws fully in the direction indicated. (Remove and keep safe). Always lock these last before transit or shipping.



CDS Player (from serial no. 146541)


transit locks (continued)

- 3 Unlock the transit screws fully in the direction indicated. (Remove and keep safe). Always lock these first before transit or shipping.






cds player operation

- 1 Place the compact disc on the platter. Make sure it is seated properly.



CDS Player (from serial no. 146541)

cds player operation (continued)



cdx CDX Player Operation

There are four buttons situated on the right hand side of the front panel. Press to activate. Two of these buttons operate differently depending on whether the player is in load condition (before the **play** button has been pressed). The player returns automatically to load condition either at the end of the last track of a programme or when the drawer is opened and closed.

previous

In load condition searches the table of contents backwards, either one track at a time, or sequentially if you hold the button depressed. Then press play to play the track chosen. In play condition mutes while searching the table of contents backwards, and then plays the track chosen without further command.

next

The next function operates in the same way as the previous function, but moving forwards through the disc instead of backwards.

stop

Stops the disc rotating, returns the laser to its inner position, and resets the player to load condition.

play

Causes the player to enter play condition. The loaded disc will start to play, beginning with track one, unless another track has been selected. If you press play while a track is already playing, the track will be re-started. When an HDCD encoded compact disc is loaded the CDX automatically recognises it and decodes the relevant information. The display will read HDCD for a few seconds after play is pressed (from load condition).

These functions are duplicated on the remote control which also provides many additional facilities. For further information refer to the instructions on page 18.

On the far right of the display are four indicators.

pause

When lit, the display shows that pause has been selected from the remote control.

time

When lit, the display shows total time (in load condition) or elapsed time of track being played (in play condition). To the left of these indicators is an alphanumeric display for track and index numbers, OR time in minutes and seconds, OR various system messages (eg: play, err etc). The full stop on the right of the window comes on when the player receives a signal from the remote control.




repeat

Shows, when lit, that repeat has been selected when using the remote control.

program

Shows, when lit, that a program has been stored. For further information please refer to page 18.

CDX Player





Connection to optional xps power supply

(for improved performance)




NB - when using the XPS the mains lead to the CDX must be disconnected



CDX Player

transit lock

- 1 Remove the transit screw (keep safe). Always replace this before transit or shipping.



cdx player operation




- 1 Open the door.


CDX Player

cdx player operation (continued)


2 Place the compact disc on the platter. Make sure it is seated properly.




3 Place the clamp on the compact disc.



4 Close the door.



5 Press play





CD5 Player Operation

There are four buttons situated on the right hand side of the front panel. Press to activate. Three of these buttons operate differently depending on whether the player is in load condition (after the PLAY button has been pressed). The player returns automatically to load condition either at the end of the last track of a program or when the drawer is opened and closed.

previous

In load condition searches the table of contents backwards, either one track at a time, or sequentially if you hold the button depressed. Then press PLAY to play the track chosen.

In play condition mutes while searching the table of contents backwards, and then plays the track chosen without further command.

next

The next function operates in the same way as the previous function, but moving forwards through the disc instead of backwards.

stop

Stops the disc rotating, returns the laser to its inner position, and resets the player to load condition play.

play

Causes the player to enter play condition. The loaded disc will start to play, beginning with track one, unless another track has been selected. If you press play while a track is already playing, the track will be re-started.

These functions are duplicated on the remote control which also provides many additional facilities. For further information please refer to the instructions on page 18.

On the far right of the display are four indicators.

pause

Shows (when lit) that pause has been selected from the remote control.

time

Shows total time (in load condition) or elapsed time of track being played (in play condition).


repeat

Shows (when lit) that repeat has been selected when using the remote control. To the left of these indicators is an alpha-numeric display for track and index numbers OR the time in minutes and seconds, OR various system messages, (eg "Err" etc). The full stop on the right of the window comes on when the player receives an infra red signal from the remote control.

program

Shows (when lit) that a program has been stored. For further information please refer to the remote control instructions on page 18.


CD5 Player




please note

The RC5 input fitted to cd5 players manufactured after March 2001 is designed to accept external control signals for multi-room applications. Contact your dealer for further information on its use.



The cd5 features various technologies to reduce microphonic effects, in particular a compliant mounting for the main circuit boards and the din sockets on the rear. Some movement of the board and sockets when connecting/disconnecting is normal.



cd5 connection to flatcap 2 power supply



flatcap 2 power supply




Interconnect Cables	
180' 5 to 5 pin	—
240' 5 to 5 pin DIN	—


CD5 Player

transit locks

- 1 Remove the transit screws (keep safe). Always replace this before transit or shipping.




cd5 player operation




CD5 Player

cd5 player operation (continued)


2 Place the compact disc on the platter. Make sure it is seated properly.




3 Place the clamp on the compact disc.



4 Close the door.



5 Press play



n2

narcom 2 remote handset

NARCOM 2 is a multi-functional remote control handset designed to be used with Naim Audio CD players, integrated amplifiers, pre-amplifiers and preset tuners. The handset control configuration is based around three types of keys: System Component Keys, Global Keys and Soft Keys.

1 System Component Keys

These keys switch the operation of the "Soft Keys" into modes appropriate to each system component (preamp, CD or tuner).


preamp: Switches the action of the Soft Keys to that appropriate for an integrated or pre-amplifier.

cd: Switches the action of the Soft Keys to that appropriate for a CD player.

tuner: Switches the action of the Soft Keys to that appropriate for a preset tuner.

2 Global Keys

These keys operate specific component functions regardless of the System Component Key setting.



preamp

vol (up and down): Adjusts the amplifier output volume and the volume control position.

mute: Reduces the amplifier output volume to zero. A second press restores the volume. The **mute** button on the amplifier will illuminate when mute is selected.

bal (left and right): Adjusts the output channel balance.

Some Naim amplifiers have control of balance available only from the remote handset. On these products the balance will automatically "centre" as it reaches the mid point. Balance centring is indicated by a flashing volume control indicator. To resume adjustment once the balance has centred, **bal** key must be released and re-pressed.

mon: The **mon** button enables the output of a 3-head tape machine to be heard while recording in order to check the "off-tape" signal. The source to be recorded is chosen by the input selector buttons in the normal way.

After pressing **mon**, select the input to which your machine is connected. A second operation of the **mon** key restores normal output.

compact disc

prev: Selects the previous track. From a stopped position **prev** will select the last track.

next: Selects the next track.

stop: Stops the CD. Holding the **stop** key for more than a second will also cancel previously set-up program and display preferences.

play: Plays the CD. Pressing **play** while a track is playing will return the player to the beginning of that track.

<<: Fast reverses the CD when in play mode.

>>: Fast forwards the CD when in play mode.

repeat: Puts the CD into repeat mode. A complete disc or programmed disc selection will repeat until **stop** is pressed.

pause: Pauses a playing CD. Pressing **pause** a second time will start the disc again.

tuner

mode: Switches the tuner sequentially through "frequency", "scan" and "preset" modes. Modes are indicated by the indicators on the tuner display.

up & down: These keys both have three possible functions depending upon the selection of the **mode** key. In **frequency** mode the up and down keys adjust the tuning frequency in 0.05MHz steps. In **scan** mode the up and down keys will cause the tuner to search for stations. In **preset** mode the up and down keys will tune to the next numbered preset.

mono: Toggles between mono and stereo operation. The tuner display will indicate stereo when both stereo operation is selected and a stereo signal is received. The **mono** button on the tuner will illuminate when **mono** is selected.

3 Soft Keys

These keys operate functions depending on the System Component Key setting.

numeric keypad: In **preamp** mode the numeric keys will switch between the amplifier inputs (1 - cd, 2 - tuner, 3 - tape, 4 - av, 5 - aux 1, 6 - aux 2). In **cd** mode the numeric keys will select tracks. In **tuner** mode the numeric keys will select tuner presets or can be used directly to input station frequencies.

prog: In **preamp** mode the **prog** key function varies depending upon the specific amplifier model in use. Firstly, some models incorporate a programmable volume control system that enables different source component output levels to be matched. Secondly, some models incorporate optional automatic source switching which will switch the input of the amplifier as soon as any handset key appropriate to a particular source is operated. For example, if the tuner input is selected on the amplifier and the **CD play** key is operated on the handset, the amplifier will switch to the CD input. Thirdly, if you have a surround sound processor connected to the A/V input, the volume control on the amplifier can be disabled, allowing the processor to take over control of the output level from the power amplifier stage (unity gain).

To program the volume control for each input first set the volume control to a comfortable listening level with the loudest source (probably CD). Enter program mode by pressing and holding the **prog** key until the amplifier volume control indicator flashes. Select the input to be adjusted using the handset and use the **vol up** and **down** keys to set the volume to a comfortable listening level. The amplifier volume control will not rotate during this operation. Select a further input to adjust. To exit program mode press and hold the **prog** key until the volume control indicator stops flashing, or operate any control on the amplifier.

To access automatic source switching enter program mode as described above. Use the handset **mon** key to toggle automatic switching on and off. The **mon** button on the amplifier will illuminate when source switching is automated. Exit the program mode as above.

To utilise the surround sound processor unity gain function, enter program mode as described above. Use the handset **mute** key to toggle the function on and off. The **mute** button on the amplifier will illuminate when unity gain is selected. Exit the program mode as above. **The unity gain function should only be used where the amplifier is used in a correctly configured A/V system. Damage may result if the unity gain feature is used inappropriately.**

To return to the default settings, press and hold the **prog** key until the amplifier volume control indicator flashes. Press and hold **disp** key until the volume control indicator stops flashing.

In **cd** mode the **prog** key enables specific CD tracks and their play order to be selected. To select a play order select a track number from the numeric keypad followed by the **prog** key until the desired selection is complete. During selection, the track number indicated in the player display will be followed by either "P", "-", or a space. "P" indicates that the track is already selected. "-" indicates that the track can be selected. A space indicates that there is no more memory available.

The **prog** key can also be used to delete tracks from a play order. To delete a track, press and hold the **prog** key until the **prog** indicator in the CD display illuminates then delete the track or tracks using the numeric keypad followed each time by a further operation of the **prog** key. During deletion the track number indicated in the player display will be followed by either "C", "-", or a space. "C" indicates that the track is already deleted. "-" indicates that the track can be deleted. A space indicates that there is no more memory available.

The play order can be reviewed by pressing **prog** while the player is either stopped or playing. The player display will then scroll through the selected tracks. The **prog** indicator on the player display will illuminate when a play order has been programmed. To clear memory press and hold the **stop** key.

In **tuner** mode the **prog** key enables specific FM station frequencies to be assigned to preset memory. To assign a station to a preset first tune manually by inputting the station frequency directly from the numeric keypad or by using the **up** or **down** keys (or **scan**). Press and hold the **prog** key on the handset. The tuner is now in **preset programming mode** - the preset indicator will flash and the display will show "--". Press the desired pre-set number from the numeric keypad. The display will show "-" or "P" if the preset number is already in use. Exit from program mode and save the new or overwritten preset by pressing and holding the **prog** key. To exit program mode without saving (or overwriting) a preset select "0 0" on the numeric keypad. To erase a preset number, select the preset and press and hold the **display** key. To clear all preset numbers press and hold the **program** key followed by the **display** key.

display: In **cd** mode the **display** key will scroll through these options: tracks ("time" indicator off), time ("time" indicator on) and display off. In **tuner** mode the **display** key will simply toggle between on and off.

newcomer

CD Player Maintenance

It is very important for reliable operation of Naim CD players to ensure that the surfaces of the transport platter and the inside of the disc clamp are free of dust, fibres or other debris which can prevent the disc from sitting properly, causing it to slip. Although slight, this slippage may make it difficult or even impossible for the machine to find tracks.

Do not, under any circumstances, use any solvents or fluids for the cleaning process.

cds, cdx and cd5 player

Take a piece of Blu-tak and lightly apply it to the top surface of the magnetic metal hub, picking up any material attached to it. Brush the plastic outer edge lightly with your finger or a soft brush to ensure that it is dust and particle free.

Similarly, clean the clamp with Blu-tak, to remove debris from the three locating pins on its underside, but take care not to damage the rubber pressure pads. Brush them lightly with your finger or a soft cloth.

Specifications

cds

Frequency Response	10Hz-18kHz ± 0.1 dB - 0.5bd)
Output Level	2.0V rms at 1kHz
Output Impedance	50 ohms nominal
Phase Response	Linear, absolute phase correct
De-emphasis	± 0.1 dB referred to main response
Distortion & Noise	<0.1% 10Hz-18kHz at full level
Laser Type	Semiconductor AlGaAs
Wavelength	780nm
Mains Supply	100V, 115V, 230V 50 or 60Hz
Case Size (H x W x D)	76 x 430 x 300 mm

cdx

Frequency Response	10Hz-20kHz ± 0.1 dB - 0.5bd)
Output Level	2.1V rms at 1kHz
Output Impedance	10 ohms maximum
Phase Response	Linear, absolute phase correct
De-emphasis	± 0.1 dB referred to main response
Distortion & Noise	<0.1% 10Hz-18kHz at full level
Laser Type	Semiconductor AlGaAs
Wavelength	780nm
Mains Supply	100V, 115V, 230V 50 or 60Hz
Case Size (H x W x D)	76 x 430 x 300 mm

cd5

Frequency Response	10Hz-20kHz ± 0.1 dB - 0.5bd)
Output Level	2.0V rms at 1kHz
Output Impedance	10 ohms maximum
Phase Response	Linear, absolute phase correct
De-emphasis	± 0.25 dB referred to main response
Distortion & Noise	<0.1% 10Hz-18kHz at full level
Laser Type	Semiconductor AlGaAs
Wavelength	780nm
Mains Supply	100V, 115V, 230V, 50 or 60Hz
Case Size (H x W x D)	58.4 x 432 x 301 mm

EC Declaration of Conformity to Appropriate Standards

Manufacturer

Naim Audio Limited
Southampton Road
Salisbury England
SP1 2LN

Products

cds, cdx, & cd5 players
xps and flatcap 2 power supplies

Safety

HD 195-S6
EN 60 065

EMC

Emissions Tested to EN 55013
Sound and television broadcast receivers and associated equipment

Immunity Tested to EN55020
Electromagnetic immunity of broadcast receivers and associated equipment

In accordance with CISPR 16-1
Radio disturbance and immunity measuring apparatus

CISPR 16-2
Methods of measurement of disturbances and immunity

IEC 801-2 8KV (air gap)
4KV (contact)
(performance criterion B)

IEC 801-3 3V/m 20dB
(performance criterion A)

IEC 801-4 1KV (AC lines)
0.5KV (signal lines)
(performance criterion B)

OWNCD • issue 6 • May 2001

Naim Audio Southampton Road Salisbury England SP1 2LN
Tel: +44 (0)1722 332266 www.naim-audio.com